

HOW TO USE



Sani Professional® QuatCheck Kit

For use with No-Rinse Sanitizing Multi-Surface Wipes

The QuatCheck Kit measures the concentration of Quaternary Ammonium in the sanitizing solution expelled from the Sani Professional® No-Rinse Sanitizing Multi-Surface Wipes. Not only does the QuatCheck Kit offer peace of mind that your hard nonporous food contact surfaces are being properly sanitized, it is also a great tool for when the health inspector comes around.



1a Remove the plunger from the syringe and insert a Sani Professional® sanitizing wipe. More than one wipe may be required to express the appropriate amount of liquid for testing.



1b Slowly push the plunger down into the syringe to express the liquid into the jar.



2 Dip a quat test strip into the liquid solution and hold still for 3 seconds.



3 Remove the test strip and shake once to remove excess liquid.



4 Wait 1 minute for the test strip to change color, then match the color chart on the bottle with the corresponding PPM level.



5 Complete color matching within 15 seconds. Sani Professional® No-Rinse Sanitizing Wipes should read between 350 and 400 PPM.



saniprofessional.com